


# Instruction Manual

LEBENSSTIL  
KOLLEKTION

LKCH-9900TIS




The cooker hood and its filter should be cleaned regularly in order to keep in good working order!

## Warning

- ☆ Keep your children out from using the cooker hood.
- ☆ Your cooker hood is for domestic use only, not suitable for any commercial usage.
- ☆ Any installation work must be carried out by a qualified electrician or competent person.
- ☆ The cooker hood and its filter mesh should be cleaned regularly in order to keep in good working order.
- ☆ Before cleaning, always ensure that you have switched off the hood.
- ☆ Clean the cooker hood according to the instruction manual
- ☆ If there is any fault with your cooker hood, please call out service department
- ☆ Please keep the room draughty when your cooker hood and gas hob are working.
- ☆ Do not exhaust the gas from cooker hood through the same heated flue which is for the gas from gas hob or other kitchen appliances.
- ☆ Before installation and usage, read all the instructions
- ☆ To ensure that you could get our guarantee for your cooker hood, please provide the warranty card and purchase receipt, or the guarantee will not be offered.

## Function and Feature

1. The cooker hood is made of high quality materials with streamlined design according to technical and physical engineering theory, high end luxury and modern, also there are kinds of styles for your option to perfect your kitchen.
2. Equipped with a large power low noise electric motor and centrifugal leaf, it produces strong suction, low noise, non stick grease filter and easy to clean.
3. With the isolated low voltage circuit board control, 12vAC input, the lights are more concentrative and safe.
4. The grease filter is easy to remove and clean.
5. Motor and other interior parts need to be wiped lightly only.
6. Special wind tunnel construction and oil collector design, avoiding redundant grease left in the flue.



Pic-1


## Installation

1. The cooker hood must be placed at a distance of 65-75cm (26-30 inch) from the surface for the best effect. See Pic. 1.
2. For safety, the ceiling should be bear at 120kgs, and the thickness should be more than 30mm. Drill a hole with  $\Phi 170\text{mm}$  on the ceiling as shown on Pic. 2.
3. According to the hanging board, drill 9 holes in the ceiling, see Pic. 2. 9 pcs ST6 $\times$ 40mm big flat screws will be used to fix the hanging board on the ceiling (if for concrete ceiling, pls use 8 pcs of exploded screws for installation).
4. See Pic. 3, according to the dimension in PIC1 and calculate the length of iron. Use 9 pcs M4 $\times$ 10 screws and M4 nut with gasket to fix the iron reinforcement plate and the second second iron (the overlap length of angle iron can not less than 100MM). At the same time, use 9 pcs M4 $\times$ 10 screws and M4 nuts connect the angle bracket and the angle iron.
5. See Pic. 4, use 6pcs ST4 $\times$ 10 to fix the angle iron with the angle on the housing, then install the outside stainless steel chimney.
6. See PIC5, install the extension tube.
7. See PIC6, through the 170MM round hole on the ceiling, lead one side of the extension pipe out of the room, at the same time, hole up the housing.


8. See PIC7, use 6pcs M4x10 screws and M4 gasket, fix the whole housing on the hanging board.
9. See Pic. 8, pull up the inside chimney. Use 3 pcs St3x8 screw to fix the inside chimney on the hanging board.
10. Use the same method to install another hood.
11. See Pic.9, take off filter.
12. See Pic 10, take off the decorative ring.
13. Install glass, decorative ring, filters according to Pic11,Pic12,Pic13.




Pic-2




Pic-3




Pic-4




Pic-5




Pic-6



Pic-7




Pic-8




Pic-9




Pic-10



Pic-11



Pic-12




Pic-13

## Cleaning and Maintenance

Change and cleaning the anti-grease filters

- Tear down your cooker hood as per the approach shown on Pic. 9
- You can clean the filter as below :
  1. Soak them for about 3 minute in hot water (40-50 degrees) with a grease-loosening detergent then brush it gently with a soft brush. Please do not apply too much pressure ,avoid to damage it .
  2. It can be put into a dishwasher with detergent ,set the temperature at around 60 degrees.
- Please do not use abrasive detergent for it will damage the hood.
- **Make sure that the hood is shut off before cleaning.**


Pic-9



## Installation (Pic.10)

- If the hood without extension pipe, it should be installed carbon filter which decrease strong smell produced by cooking.
- Normally the carbon filter should be changed at three or six months according to your cooking habit.


**Attention: The carbon filter should be bought additionally**



Pic-10

How to operate the control, see Pic. 12

- a. Press the button “Low”, the inner indicator light of switch starts shining, the motor is running at low speed.
- b. Press the button “Mid”, the inner indicator light of switch starts shining, the motor is running at medium speed.
- c. Press the button “High”, the inner indicator light of switch starts shining, the motor is running at high speed.
- d. Press the button “Light”, both lights start shining. Press the button again, the lights are switched off then.



Pic-12

# Lebensstil

KOLLEKTION

Distributed by:

**Kollektion Distribution Sdn. Bhd.** (506854-A)

Lot 11A, Jalan 223, Section 51A,

46100 Petaling Jaya,

Selangor Darul Ehsan, Malaysia,

Tel: +603-7954 5200 Fax: +603-7954 5705

[www.kollektion.com.my](http://www.kollektion.com.my)

Careline  
1-800-881-770